

1. Aftermarket lock(s) should be installed two (2) inches from the side of the door. (Figure 1)
2. With the door open, mount the lock(s) on the frame using supplied self-drilling screws. (Figure 2)

